

 Tag us on Instagram!  
[@sternmastermarinetools](https://www.instagram.com/sternmastermarinetools)

 Follow us on Facebook!  
[Facebook.com/SternmasterMarineTools](https://www.facebook.com/SternmasterMarineTools)



[CustomerService@Sternmaster.net](mailto:CustomerService@Sternmaster.net)

1-800-305-8117

[www.SternmasterMarine.com](http://www.SternmasterMarine.com)

[Facebook.com/SternmasterMarineTools](https://www.facebook.com/SternmasterMarineTools)

**STERNMASTER**  
MarineTools™ 

---

STERNDRIVE INSTALLATION CART



## ME-186 PRODUCT MANUAL

---

[CustomerService@Sternmaster.net](mailto:CustomerService@Sternmaster.net)

411 N Centennial St  
Zeeland, MI 49464

[SternmasterMarine.com](http://SternmasterMarine.com)  
1-800-305-8117

## ASSEMBLY INSTRUCTIONS ME-186 STERNDRIVE INSTALLATION CART



#	(Qty) Part Name	#	(Qty) Part Name
1	(1) Upright	5	(4) 1/2" x 1 1/4" Bolts
2	(1) Base	6	(8) 1/2" Washer
3	(4) Casters (2 Locking)	7	(4) 1/2" Lock Nut
4	(4) Lock Washers	8	(1) Oil Pan/Parts Tray

	<p><b>Casters and Lock Washers</b></p> <p>Thread the caster with a locking washer into the base. The locking casters should be placed in the rear (where the upright is attached)</p>
<p>Attach Hardware</p>	<p><b>1/2" Hardware</b></p> <p>Attach the upright to the base using the four 1 1/4" bolts and hardware provided.</p>
<p>Lead Screw</p>	<p><b>Continued Maintenance</b></p> <p>You should oil the lead screw, reapply as necessary. Recommended oil is a 90W or equivalent.</p>
	<p><b>Oil Pan/Parts Tray</b></p> <p>The Oil Pan/Parts Tray is removable and sits on the legs for convenient storage of oil pans, props, etc.</p>